



Kentronics®
1467 Bribie Island Road
Ningi, Qld, 4511

ABN: 36 106 545 950

Ph: 07 5429 5363

Fax: 07 5429 5364

Mobile: 0417 377 480

Email: kenton@kentronics.com.au

Electroline P/Supplies explained

- If an E/Line has no P/Set K/Pad & the service fitter removes a L/F & installs a H/F P/S – The Bowser performs as required.
- If an E/Line has no P/Set K/Pad & the service fitter removes a H/F & installs a L/F P/S – The Bowser will not open hose solenoid (Slow-flow delivery only).
- If an E/Line has a P/Set K/Pad & the service fitter removes a L/F & installs a H/F P/S – The Bowser will run over P/Set amount.
- If an E/Line has a P/Set K/Pad & the service fitter removes a H/F & installs a L/F P/S – The Bowser will not open hose the solenoid (Slow-flow delivery only).

Electroline Browsers requiring a H/F P/Supply will have 5 pins in the 6 way power connector harness socket

Electroline Browsers requiring a L/F P/Supply will have 4 pins in the 6 way power connector harness socket