


Basic FC6000


Rear Panel Plug Locations



Basic FC6000

With combined Epson printer and
customer display


Rear panel plug locations



Basic FC6000

With Epson printer and remote customer display

Rear panel plug locations



Basic FC6000

With combined Epson printer &
customer display and Gilparco T24
Comms

Rear panel plug locations

