

Procedure to set up the PEC pump (Standard Alone)

Turn the key to function mode

Press 10, then short the diagnostic pin on left hard side display, (you will hear a beep)

The system will restart and back to function mode

Do the following menu to set up the pump

Press 22 then FILL, Press 1 then FILL (Activate pump, Front)

Press 23 then FILL, Press 1 then FILL (Activate pump, Rear)

Press 31 then FILL, Key in the <Price> FILL (Set Price 1)

Press 51 then FILL, Key in the <Price> FILL (Set Price 2)

Since you don't have input process board connected, you are not able to view K factor, that is all you need to set up the pump for stand alone.

Turn the key back to normal.