

Set up procedure for PEC CEEPEC/MultiPEC

TURN OFF THE PUMP AT LEAST 5 SECONDS THEN RESTART THE PUMP

Turn the key to get into program mode

Erase setup: Press 10 then short the Diag pin on the display board, press FILL key twice, the pump should restart and memory is erased.

Procedure to setup the pump

1 Activate the hoses (by default all hoses are deactivated)

Hose 1	Front side	menu 22
Hose 1	Rear side	menu 23
Hose 2	front side	menu 42
Hose 2	Rear side	menu 43
Hose 3	Front side	menu 62
Hose 3	Rear side	menu 63

To activate a hose press key 1 followed by the FILL key
To deactivate a hose press key 0 followed by the FILL key

2 Setting the pump Number

Hose 1	Front side	menu 20
Hose 1	Rear side	menu 21
Hose 2	front side	menu 40
Hose 2	Rear side	menu 41
Hose 3	Front side	menu 60
Hose 3	Rear side	menu 61

To enter a pump number press key ie 20 followed by the FILL key then press the pump number followed by the FILL key

Enter a pump number with 00 to set the pump in standalone